


BUILDING VOID71 & OCTO88 INTO A HOUSING

VENTILATION

The module has air-intakes and exhausts at the bottom (rectangular holes are exhausts, the round ones are intakes). This means the warm and cool air have to be separated. The airflow inside the housing is enforced by an internal fan.



HIDING THE UNIT

The base can be covered with anything that isn't magnetic. So wood or aluminum is possible. However, there needs to be a hole in the center of the unit for the optical sensor. Our systems use an optical sensor on the base and a reflector on the floating carrier. This path must be unobstructed for the levitation unit to function.

ADDING COVER

When adding a transparent cover make sure to leave the 2 mm gap open. (the carrier doesnt need cooling)

THE IMPORTANT THINGS

Try not to stretch the limits of the module in terms of a too heavy or too high object. (this will create heat.)

Make sure there is active ventilation.

Make sure the airflow is bottom to top.

Make sure the hot air and cool air don't mix.

EXAMPLE

